



Instructions

Step 1

Measure the distance between the edge of the cut-out and the end of the tremolo block.

Step 2

Screw in the set screws at the end of the Tremolo Deadlock according to the measurement from step 1.

Step 3

Lock the set screws by holding them in place with the 2 mm Allen key (7) and carefully tighten the M4 nuts (3) with the 7 mm Combination wrench (9).

Step 4

Remove the springs and spring claw from the guitar. Keep the spring claw screws (A) for the next step.

Step 5

Install the Tremolo Deadlock with the screws from step 4 (A).

Step 6

Screw the appropriate set screws (2) into the Tremolo Deadlock so that the tremolo block is completely locked.

Step 7

Lock the front set screws (2) with M4 nuts (3) as in step 3.

Step 8

Install the ground wire with the cylinder head screw (4). The ring terminal (5) can optionally be attached to the ground cable beforehand.

Step 9

Have fun!

Package content

- ① 1 x Tremolo Deadlock
- ② M4 Set screw
4 x 8 mm
4 x 12 mm
4 x 16 mm
- ③ 4 x M4 Nut
- ④ 1 x M3 Cylinder head screw
- ⑤ 1 x Ring terminal
- ⑥ 4 x M4 Nut
- ⑦ 1 x 2 mm Allen key
- ⑧ 1 x 2,5 mm Allen key
- ⑨ 1 x 7 mm Combination wrench
- Ⓐ Spring claw screws (reuse your own)

**More information at
tremolo-deadlock.com**